



# FORO 1650 DRILL

## Operations and Maintenance Manual

---

January 10, 2025

NSF Ice Drilling Program  
University of Wisconsin-Madison Space Science & Engineering Center  
All Rights Reserved.

Table of Contents

1.0 Purpose ..... 1

2.0 Scope..... 1

3.0 References ..... 1

4.0 Definitions..... 1

5.0 Responsibilities ..... 1

6.0 Records ..... 1

7.0 Safety Notice ..... 2

8.0 Overview ..... 4

9.0 Drill System Layout..... 5

10.0 Tent Site Preparation and Construction..... 5

    10.1 Drill Trench..... 5

    10.2 Tent Construction ..... 8

11.0 Drill System Installation ..... 10

    11.1 Winch Footer and Slot Excavation ..... 10

    11.2 Control Room..... 11

    11.3 Power System ..... 12

    11.4 Control System..... 13

    11.5 Winch and Tower ..... 21

    11.6 Level Wind ..... 23

    11.7 Winch Cable ..... 24

    11.8 Core Pullout Table..... 24

    11.9 Core Processing System ..... 24

    11.10 Vacuum System..... 26

    11.11 Fluid Handling ..... 27

    11.12 Chip Processing ..... 28

    11.13 Ventilation ..... 30

12.0 Drill Sonde ..... 31

    12.1 Sonde overview..... 31

    12.2 Anti-Torque ..... 32

    12.3 Motor Section ..... 33

    12.4 Chips Chamber ..... 33

    12.5 Hollow Shaft..... 34

    12.6 Core Barrel ..... 34

**Foro 1650 Drill - Operations and Maintenance Manual**

**Document #8614-0022**

**Version: 1.0**

---

12.7	Outer Tube.....	35
12.8	Cutter Head.....	35
12.9	Bailer.....	37
12.10	Reamers.....	38
13.0	Drill Run Operations Guide.....	38
14.0	Winterizing for Multi-Year Projects.....	39
15.0	Shipping and Inventory lists.....	40
16.0	Appendix A: Preventive Maintenance Checklists.....	41
17.0	Appendix C: Foro 1650 Drill Run Operations – Reference Guide.....	44
18.0	Appendix B: Drill Log Template.....	46

This page left intentionally blank.

## **1.0 PURPOSE**

This document describes the operations and maintenance of the Foro 1650 Drill system.

## **2.0 SCOPE**

This document applies to the operations and maintenance of the Foro 1650 system including all major field-deployable sub-systems.

## **3.0 REFERENCES**

- 1008-0014 SSEC Project Safety Plan
- 8501-0019 IDP Drill Slot Confined Space Training
- 8614-0003 Foro 1650 Science Requirements
- 8614-0004 Foro 1650 Engineering Requirements
- 8614-0018 Foro 1650 Failure Mode and Effects Analysis
- 8614-0022 Foro 1650 Failure Mode and Effects Analysis – Table
- 8614-0110 Foro 1650 Safety Trainings
- 8614-0111 Foro 1650 Equipment Manuals
- 8614-0112 Foro Drill Bulkhead Seal Installation and Maintenance
- 8614-0113 Foro 1650 Winch Cable Termination Procedure
- Note: Referenced drawings can be found in the IDP SolidWorks EPDM vault.

## **4.0 DEFINITIONS**

Foro 1650 – Formerly named the Intermediate Depth Drill (IDD)

IDP – NSF Ice Drilling Program

NSF – National Science Foundation

QAS – Quality Assurance and Safety group

SSEC – University of Wisconsin-Madison, Space Science & Engineering Center

## **5.0 RESPONSIBILITIES**

IDP Engineering is responsible for the generation and maintenance of this document.

SSEC QAS is responsible for ensuring that this document is created, reviewed, approved, maintained and changed per applicable SSEC processes.

Project personnel are responsible for understanding this document.

## **6.0 RECORDS**

None.

## 7.0 SAFETY NOTICE



The SSEC Project Safety Plan, 1008-0014, describes in detail the processes used to define, evaluate, mitigate, report, and communicate potential and real safety concerns for equipment and field projects. Document 8614-0110 contains safety training specific to the Foro 1650. This section highlights key safety concerns for the Foro 1650 Drill system and is not meant to replace the SSEC Project Safety Plan. Only trained personnel should operate the Foro 1650 Drill. All drillers or those operating or assisting with operations of the Foro 1650 Drill must read and understand the following safety precautions prior to operating this device.

### Personal Protective Equipment (PPE)

- Personnel shall wear appropriate PPE during drilling operations, including:
  - Safety glasses
  - Footwear – safety toe and liquid-proof
  - Hearing protection
  - Gloves - liquid-proof and cut-resistant
  - Appropriate clothing – avoid loose clothing, jewelry, and loose long hair. Liquid-proof outerwear is recommended.
  - Hard hats – required when working near suspended loads or when working below other personnel.

### Mechanical Safety

- Cutters – The ice cutting bit is extremely sharp. Operators should use care whenever handling bits and wear protective gloves.
- Pinch Points – There are several areas on the drill where a finger, hand, arm or clothing could be pinched. Operators should identify all pinch points prior to operation and should be mindful of all such points during operation.
- Suspended Loads – Users shall never stand under suspended loads. Injury may result from a moving, rotating, falling or unbalanced load.
- Rotating Components – The drill head may be rotated under power while servicing the drill on the tower. Keep hands, limbs, loose clothing, and hair away from any rotating components. The drill operator must make sure it is safe to rotate the cutter head and that others working with the drill are made aware it will be turning before it is turned on.
- Eye Protection – Eye protection must be worn whenever handling fluids or fluid soaked cuttings.
- Cold Hazard – Drill components may be extremely cold when pulled from the borehole. Always wear appropriate gloves when handling.
- Slippery Surfaces – The drill trench floor and handrails may become slippery when wet with drilling fluid. Use caution whenever walking on the wet floor or grabbing handrails.

**Electrical Safety**

- Electrical shock – Extreme care shall be taken when assembling, disassembling and servicing electrical equipment. Always disconnect power before servicing equipment. Proper lockout tagout procedures shall be followed and only qualified people should be working on electrical equipment.
- Grounding – Because the drill sits upon a large thickness of ice, a common earth ground cannot be established. Workers shall ensure that all drilling equipment is bonded together to a common ground back to the generator(s).

**Chemical Safety**

- Use fluid resistant gloves and eye protection when handling drilling fluid or other chemicals.
- Use care and observe all safety warnings when handling chemicals.
- Combustibles – This system uses combustible fuel for the generator and may be supplied with ethanol for freeing a stuck drill. Take care to properly store all combustibles away from all major heat sources.
- Secondary Containment – Fuels and other fluids should be stored in secondary containment to prevent spills and unplanned release. Secondary containment devices must be requested from the logistics provider.
- Drilling Fluid Hazard – If used, note any potential for combustion or potentially present health hazards. Proper PPE must be worn when handling and using drilling fluids.

**Environmental Safety**

- Cold – This drill will be deployed to extremely cold climates. Operators shall wear outerwear suitable to protect themselves from the cold and should monitor their own and fellow workers' activities for exposure to cold.

**Confined Space for Slot Entry**

- Retrieval equipment – Including a harness, retrieval line (lifeline), and tripod for lifeline
- Hardhat or climbing helmet
- Belt O2 Monitor – For detection of dangerous levels of gasses from drill fluid
- Radio
- Gloves

## 8.0 OVERVIEW

The Foro 1650 Drill is the next generation of the Danish Hans-Tausen Drill and Danish Deep Drill, with the capability of producing 2-meter long cores.

The Foro 1650 Drill is sufficiently portable for coring at a wide variety of sites, and capable of retrieving 98 mm diameter core from the surface down to 1650 meters depth in two field seasons.

In addition to the drill itself, the Foro 1650 system includes the following ancillary items:

- Core Processing System: core barrel puller, trays, vacuum, saw, and tables
- Chip melter to recover the drill fluid from the chips created by drilling the core
- Drill fluid handling system
- Vacuums to clean the drill cable and the core
- Pilot hole system
- 7" and 9" diameter reamers
- A 4.9 m (16 ft.) x 19.5 m (64 ft.) x 2.8 m (9 ft.) un-insulated Weatherport fabric building for housing the drilling and core processing operations

The Foro 1650 Drill is designed and constructed to be transportable by Twin Otter or Bell 212 (or similar) helicopter, though numerous flights are required. For field projects lasting more than one season, most equipment is left onsite to "winter-over". To drill to 1650 meters depth in two field seasons, a 10-person field-team for 24-hour per day drilling and core handling operations is required. This includes seven drillers.



## 9.0 DRILL SYSTEM LAYOUT

A plan view of the drill system layout is shown in Figure 1. See drawing 8614-0500 *Drilling Tent Assembly* for additional views and details.




Figure 1. Foro 1650 Drill System Layout - Plan View

The drilling floor inside the tent is recessed 1.5m (55") to permit the use of a lower height tent and to help keep the building cooler by having less wall area exposed to the sun. A set of stairs is located inside the door on either end of the tent to access the drilling floor. A smaller tent within the drill tent, which is heated and ventilated, serves as the control room for operating the drill and as a warming area. Windows on two sides of the control room provide a good view of the drill floor and the room is large enough to comfortably hold four people.

## 10.0 TENT SITE PREPARATION AND CONSTRUCTION

### 10.1 Drill Trench

The drill site should be laid out with the prevailing wind direction in mind. To minimize drifting, the drill tent should be positioned with one of the end walls pointing into the wind. Cargo lines should also run lengthwise with the wind and rows should be spaced out enough so equipment can get between them to clear snow drifts. Empty pallets, low boxes, and all electrical runs should be well marked with flags so they can be found if they get buried and to prevent them from getting run into with equipment.

The base layer of the drill tent footing is a layout of 1.0 m x 0.5 m sections of Geoblock Porous Pavement grid sections. They are installed directly on a level snow surface with the smaller grid openings facing up as shown in Figure 2. This allows the drill tent, which will be assembled off the end of the trench, to easily slide over the footer.



Figure 2. Orientation of Geoblock for footing installation

Install two lines, consisting of 21 sections (68.9') each, of Geoblock that are spaced 15' apart as shown in figure 3. Level and backfill the panels with snow as you go. The two lines should create a level plane for the tent to sit on. Drawings 8614-0500 *Drilling Tent Assembly* and 8614-0501 *Drill Site Trench\_Slot Cutout* show the location of the footers in relationship to the borehole and trench. The end of the footer that runs long will be the end of the trench that the tent will be built on. Wait to place the two short lengths of footer that will be under the tent end walls until after the trench excavation has been completed.




Figure 3. Installing the Geoblock footer

Drawing 8614-0501 *Drill Site Trench\_Slot Cutout* provides the dimensions for the trench excavation. Lay the two side footers before excavating the trench. This establishes the width of the trench and provides a level surface to measure the depth from. Depending on equipment available, the trench could be excavated with heavy equipment such as a bucket loader or bulldozer or could be done by hand with chain saws. If heavy equipment is going to be used, first cut along the inside edge of the footer with a chain saw. This will provide a clean edge along the footer and help prevent the snow under it from being disturbed. You may need to repeat these cuts a few times as the trench is deepened. After excavation, end walls will need to be built and then backfilled. Either wood or snow block wall will work. Before building the end walls, it is a good time to place the heavy items like the tower base, winch drum, and chip melter crates in the trench while you have a ramp.




Figure 4. Excavated trench with large cargo pieces in place and wood end walls being built.

Depending on the duration of the project and condition of the snow, a floor should be laid to stabilize the snow and prevent the work area from getting slippery. Geoblock Porous Pavement grid sections are provided for this. The grid sections are placed with the larger grid openings facing up for the best traction. The grid sections should be backfilled with snow to lock them into place and to create a smooth walking surface as shown in Figure 5. The panels are made of polyethylene, so they can easily be cut with standard wood working tools. It is recommended to not start placing the flooring until the winch footing has been set, as the flooring needs to be set around this equipment. Flooring also does not need to be placed under the control room if it is being used. However, it is a good idea to lay flooring under the core processing line to provide a good footer for the tables.



Figure 5. Installing the Geoblock flooring.

## 10.2 Tent Construction

Assemble the drill tent off the end of the trench that the Geoblock footers run long on, following the instructions for assembling the tent in 8614-0111 *Foro 1650 Equipment Manuals*. The tent should be built with the first few feet of the tent base on top of the footer tails.

Lag bolt base rails to 2x6 wood lumber making sure the joints of the boards are offset from the joint in the base and that the lag bolts don't protrude out the bottom of the lumber. Place straps at each arch to keep the base from spreading until it is secured over the trench. Diagonal straps should also be installed to keep the building square while being moved. These steps are shown in Figure 6 and Figure 7.



Figure 6. Tent frame being assembled off the end of the trench on the Geoblock footer tails.



Figure 7. Assembled tent frame with straps to keep the base from spreading.

Install the cover as described in the tent manual. However, after centering the body cover, bunch up one side and install the roof vents as shown in Figure 8. This is also a good time to install the 12" powered fans. They mount from the inside of the tent as shown in Figure 9.



Figure 8. Installing the roof vents



Figure 9. Installing the roof vent fans

Finish installing the cover, but do not tension the cover contour ropes at this time. Once the tent assembly is complete, pull it over the trench using a vehicle, tractor or winch. Be careful to keep the tent centered as there will be only a few inches on either side between the tent base and the inside edge of the Geoblock. Snow pickets are provided to secure the tent base to the snow. As the tent is being pulled over the trench, drive a picket in every 4' on each side. This will act as a guide and keep the tent centered. If these are placed properly, they will line up next to each arch once the tent is in its final position. Once the tent is in its final position, drive the pickets in until they are flush with the 2x6 to prevent them from damaging the fabric cover. Remove the internal straps and let the frame push against the pickets. Run deck screws through the picket into the 2x6. Finally, finish tensioning the cover per the manufacturer's instructions and install the stairs at either end.

## 11.0 DRILL SYSTEM INSTALLATION

### 11.1 Winch Footer and Slot Excavation

Assemble and install the Winch Footing Assembly, drawing 8614-0435, in the trench floor before excavating the slot. The footer will serve as a guide and prevent the snow edge from eroding as the slot is cut. Figure 10 shows the slot being excavated with an electric chain saw and shovels.

The Foro 1650 slot is considered a permit required confined space which falls under the 29CFR1910.146(c)(5) exemption. See the SSEC Project Safety Plan, 1008-0014, for confined space requirements. Entry into the slot requires training, PPE, and a signed entry certificate; details are outlined in the IDP Drill Slot Confined Space safety training, 8501-0019.



Figure 10. Slot excavation after the winch footing has been installed.

### 11.2 Control Room

The control room is a 5' x 8' heated and ventilated tent. Assemble the control room tent following the instructions for the control room in 8614-0111 *Foro 1650 Equipment Manuals* on the insulated two-piece floor panel. The heating/ventilation system, which includes an Energy Recovery Unit (ERV) to preheat the incoming fresh air, is then assembled on the roof as shown below in Figure 11 and Figure 12 and on drawing 8614-0581 *Control Room Assembly*. Warm air, which is turned over 53 times per hour, is supplied at the ceiling level and returns at the floor level under the operators' desk to create a down-draft air flow. Manuals for the ERV and heaters can be found in 8614-0111 *Foro 1650 Equipment Manuals*. The intake and exhaust duct should be run outside the drill tent and terminated with vertical ducts that are at least 3' high and fitted with wind directional caps.




Figure 11. Control Room with heating/ventilation system.



Figure 12. Left - Control Room assembly. Right - ERV system mount being installed.

### 11.3 Power System

The Foro 1650 drill system requires a 480V 3PH power feed with a minimum generator sizing of 25kW at sea level. The two electrical distribution panels and step-down transformer are included as part of the system along with all the interconnect cables. Install a 4' x 8' sheet of plywood to the left of the control room as shown in Figure 1 and below in Figure 13. Place the 480V panel on the left and 208V panel on the right with the transformer centered below them. Make sure the panels are mounted high enough so the doors will clear the top of the transformer. The system is plug-n-play, so no hard wiring is required. For further details, see drawing 8614-0585 *Power System Wiring Diagram* for complete system specifications and 8614-0111 *Foro 1650 Equipment Manuals* for information on the two panels and transformer. The feeder cables for the vacuum system, slot ventilation fan, and multi-tap outlets located on the other side of the drill tent will need to be buried beneath the Geoblock flooring. The 480V panel is also equipped with a 60A breaker and receptacle that can be used to feed camp power.




Figure 13. Electrical distribution panels with transformer.



### 11.4 Control System

The drill system is operated via electronic controls distributed throughout the system, Figure 14. Emergency stop buttons (E-stops) are present at the winch, control box, and console – these can be used to stop winch and tower motion at any time. All E-Stop buttons in the system must be released for the drill system to be used. The control box, console, and sonde contain the most complex and sensitive electronics in the system. These assemblies should not be opened or modified except under the clear guidance of IDP electrical engineers.




Figure 14. Foro 1650 control system layout, top view and side view.

#### 11.4.1 Control Box

The drill system requires a 208V 3 phase supply and a 480V 3 phase supply, both connected to the control box, Figure 15.

The Control Box contains:

- The Sorensen power supply that powers the drill
- 24V power supply for control voltages across the Drill System
- Two motor drives to operate the winch and tower motor
- A microcontroller to suitably translate the signals from the tower pendant to the tower actuator motor drive
- Connections to various limit switches and other peripheral devices associated with the winch and tower motors
- An E-Stop button
- Connections to the Console

The power supplied to the drill is controlled by opening a lid on the top of the control box to directly access the controls on the front of the Sorensen power supply.




Figure 15. Control box.

#### 11.4.2 Console

The Console allows the operator to control:

- The winch motor
- The drill motor, if the Drill Control Interface is configured appropriately

The Console also includes an E-Stop button, and an indicator light that is illuminated when any E-Stop in the system is activated (including if a cable carrying an E-Stop signal is disconnected).

#### 11.4.3 Winch Assembly

The winch motor is powered and controlled by the motor drive in the control box, but the level wind is only powered from the control box – it contains a closed loop control of the cable guide based on the cable position.

#### 11.4.4 Drill Tower

The Drill Tower can be tilted via the buttons on the Tower Pendant, which control the tower actuator.

The red button on the pendant is NOT an E-stop. It is used to enable the other pendant controls – when not in use, the red button should be left pressed in to disable the pendant controls.

When the red button is pulled out, the knob on the Tower Pendant can be pulled down to drive the tower towards the vertical position or pushed up to drive the tower towards the horizontal position. Tower motion will stop when either of the tower limit switches are actuated, corresponding to the vertical or horizontal tower positions. The tower should typically be moved between these two positions – operating the winch with the tower in other positions may result in unexpected movement and/or hazards to personnel and equipment.

#### 11.4.5 Sonde

The control system elements on the sonde are concentrated in the motor section. These include the circuit boards mounted to a heatsink within the motor section, the drill motor and drive, inertial measurement unit (aka navigation module), and borehole pressure sensor.

#### 11.4.6 Drill Control Interface

The Drill Control Interface, Figure 16, is a program developed in NI LabVIEW 2020, with the following features:

- Displays all the data communicated to or from the Sonde Electronics
- Allows the operator to control the operation of the drill motor
- Displays data associated with cable tension and payout, including an estimate of the weight on the bit and whether the drill is floating in the drill fluid

If desired, the Interface includes a feature whereby the operator can pass control of the drill motor to the console. It is typically run on a laptop located in the control room, near the console.



Figure 16. Drill control interface inside the control room tent.

11.4.7 Power Up Procedure

1	Visually confirm that grounding wires link all exposed metal to the control box		
2	Visually confirm that the following cables are connected:		
WM	Winch Motor cable	Control Box	Winch Motor
WMR	Winch Motor Resolver cable	Control Box	Winch Motor
WB	Winch Brake cable	Control Box	Brake Resistor
TAM	Tower Actuator Motor cable	Control Box	Tower Actuator
TMR	Tower Motor Resolver cable	Control Box	Tower Actuator
DP	Drill Power cable	Control Box	Winch Drum
LW	Level Wind	Control Box	Level Wind
SLS	Sonde Limit Switches	Control Box	Crown Sheave
TLS	Tower Limit Switches	Control Box	Tower Horizontal/ Vertical Limit switches
E-STOP	E-Stop cable	Control Box	E-Stop Button


		C1, C2, C3, C4	Console cables 1, 2, 3, and 4	Control Box	Console
		TP	Tower Pendant	Control Box	Tower Pendant
3	Confirm that the 208V and 480V breakers on the Drill Control Box are in the OFF position				
4	Confirm that the Sorensen power supply in the Drill Control Box is switched off and disabled				
5	Confirm that the controls from the Drill Console are as follows: <ul style="list-style-type: none"> <li>• Winch motor set to Stopped</li> <li>• Winch motor Coring and Tripping speeds set to zero</li> <li>• Drill speed set to zero</li> </ul>				
6	Confirm that all E-stop buttons are in the inactive position				
7	Connect the 208V and 480V plugs to the Drill Control Box				
8	Notify any nearby personnel that power is being applied by saying "Power On"				
9	Switch the 208V and 480V breakers on the Drill Control Box to the ON position				
10	Wait 30 seconds to allow for system initialization				



11.4.8 Power Down Procedure

1	Switch off and disable the Sorensen power supply in the Drill Control Box
2	Switch the 208V and 480V breakers on the Drill Control Box to the OFF position
3	Disconnect the 208V and 480V power cables from the Drill Control Box
4	Wait 10 minutes for the system to completely de-energize

11.4.9 Assembly Procedure: Sonde and Winch Cable

1	If the system is powered down, execute the Power Up Procedure (11.4.7)
2	Confirm that the Sorensen power supply in the Drill Control Box is switched off and disabled
3	Remove the straps from the Winch Drum to release the Winch Cable
4	Use the Drill Console to provide slack as necessary by paying out the winch cable
5	Assemble the Winch Cable with the Level Wind by removing components highlighted below in red, threading cable between the rollers, and replacing the removed components.



<p>6</p>	<p>Assemble the Winch Cable with the Tower crown sheave by removing components highlighted below in red, threading cable onto crown sheave, and replacing the removed components.</p> 
<p>8</p>	<p>Remove the protective cover from the end of the Winch Cable</p>
<p>9</p>	<p>Assemble the Winch Cable with the Sonde by removing components highlighted below in red, securing cable strain relief head to the antitorque, mating cable connector with slip ring, and replacing the removed components.</p> 

11.4.10 Disassembly Procedure: Sonde and Winch Cable

1	If the system is powered down, execute the Power Up Procedure
2	Confirm that the Sorensen power supply in the Drill Control Box is switched off and disabled
3	Execute the inverse of the steps of the Assembly Procedure: Sonde and Winch Cable in reverse order

11.4.11 Drill Control Interface Initialization Procedure

1	If the system is powered down, execute the <b>Power Up Procedure</b> (11.4.7)
2	Connect the USB cable from the Drill Console to the PC to be used for running the Interface
3	Open the Device Manager (Win+X then M), expand the Ports (COM & LPT) tree, and take note of the COM port associated with the Drill System
4	If the Drill Control Interface has not been run before, use the InstaCal program from Measurement Computing to configure the input channels of the USB-1808-OEM, such that all channels are single ended (SE), except for channel 0 which is differential (DIFF); set the Encoder Z input mode to Active high level
5	Start the Drill Control Interface application
6	Use the COM port dropdown to select the COM port identified in step 3 above
7	Run the program by selecting Operate > Run
8	Confirm connection to sonde, then select State > Initialize
9	Use controls at left of screen to set drill speed



### 11.5 Winch and Tower

A tilting tower design is used for the Foro 1650 system so the drill can be positioned horizontal for ice core and cuttings removal and for servicing. The tower is 6 m in length and is designed to work with a drill that has a 2 m long core capacity. The tower will also accommodate reamers or other tools up to 12 inches in diameter, if the sonde rests are removed. Specifications for the winch are shown in Table 1.

Pulling Capacity	10 kN (outer layer) – 14 kN (first layer)
Line Speed	1.0 m/s (first layer) – 1.4 m/s (outer layer)
Gearbox	56.38:1 helical bevel gear
Motor	11.7 hp, 3,000 rpm, 460 V
Cable	Rochester 4-H-220-D, 4-conductor (2 x #22 AWG, 2 x #24 AWG), 22.7 kN breaking strength
Cable Capacity	1,700 m nominal

Table 1. Winch specifications

The crown sheave is instrumented to measure cable tension and speed. The sheave also includes a cable guide to prevent the cable from coming off the sheave in the event cable tension is lost. A hard stop switch, that stops the winch, is also integrated into the cable guide in the event that the sonde-at-home switch fails. Below the hard stop is the sonde-at-home switch. This switch is used as a home reference for the drill and stops the winch and lights the sonde-at-home light on the console when the drill contacts it. The crown sheave assembly is shown in Figure 17.




Figure 17. Crown Sheave assembly

The upper and lower portions of the tower break down into 1 and 2 m long sections for easy transport. The winch drum tilts with the tower, so the sonde does not translate up or down the tower when it is being tilted. Another unique feature of this design is that additional lifting equipment is not required to install and remove the winch drum. This is possible because the axis of the winch drum translates vertically as the tower is tilted. The winch drum can therefore be rolled out of the shipping crate and onto the tower base frame and then the tower is tilted towards horizontal until the stub shaft on the gearbox lines up with the winch drum. Figure 18 shows the winch drum sitting on its shipping pallet behind the tower base.



Figure 18. Tower base and winch drum

An electric linear actuator is used to tilt the tower and is controlled with a handheld pendant. The pendant provides full variable speed control for tilting the tower. The vertical and horizontal limits of the tower are set with adjustable hard stops and limit switches. In the vertical position, the limit switch should be set so the tower makes contact with the stops. If this is not done, the tower could move until it hits the stops during core breaks. To set the stops, first set the limit switches with the hard stops backed out of the way. Then adjust the hard stops until they just make contact. This will ensure that the actuator is being stopped by the switches and that is not loading the tower base frame. The tower has four adjustable height sonde rests that can be placed anywhere along its length. It is recommended to place one at the base of the anti-torque, one under the motor section, one around the midpoint of the chips chamber, and the last one near the end of the core barrel. Adjust the height of the rests so the drill is straight and contacts them at all four points. Details of the tower and winch assembly are covered in drawing 8614-0332 *Winch and Tower Assembly*.

11.6 Level Wind

To ensure even cable winding, the Foro 1650 winch is equipped with a level wind. The level wind operates fully independent of the winch and maintains position and speed by measuring the angle the cable is coming off the winch drum. The system is designed to always keep the cable near perpendicular to the winch drum axis. The level wind assembly mounts to the tower with four screws that are called out on drawing 8614-0332 *Winch and Tower Assembly* and is powered by a single cable. The attached electrical enclosure contains the motor controller. Under a cover strip on the slide are two magnetic non-contact limit switches, one for either end of the travel. They should be set to stop travel about one cable diameter before reaching either drum flange. This will prevent the cable from stacking up at the flanges and ensure a smooth turnaround. Operators should keep a close eye on the level wind when the winch is first run after the level wind has been installed and adjust the limit switches as necessary. To remove or install the winch cable in the fairlead rollers, remove only the two M5 screws shown in Figure 19. The fairlead roller end plate can then be slid off the shafts to install the cable. The rollers are retained so no other parts will come loose when the plate is removed. Be sure to reinstall the plate before running the level wind.




Figure 19. Level wind assembly

### 11.7 Winch Cable

The winch drum is designed for winch cables up to 1,700 m long, however it will hold 1,900 m if filled to the top of the flange. This is not recommended because it leaves no room for the cable to miss-wrap. The winch cable is 7/32" diameter with four internal conductors, two #22 AWG and two #24 AWG. Full specifications for the cable can be found in 8614-0111 *Foro 1650 Equipment Manuals*. The cable is mechanically attached to the drill using the insert and helical rods from an EVERGRIP 115-3R-L termination. The insert and rods should be installed following steps 1-5 in the EVERGRIP termination instructions found in 8614-0111 *Foro 1650 Equipment Manuals*. Position the end of the insert 3" from end of the armor jacket wires. Terminate the electrical conductors following the process in 8614-0113 *Foro 1650 Winch Cable Termination Procedure*.

### 11.8 Core Pullout Table

Located at the end of the drill slot is the core pullout table. The table separates at the midpoint and the hand winch and frame assembly is removable in one piece for ease of assembly and shipping. Drawing 8614-0433 *Core Pullout Table* shows the complete assembly. The table mounts to the winch footer assembly shown in drawing 8614-0435 *Winch Footing Assembly* to keep it from moving when using the hand winch to pull out the core barrel. The table height is adjustable so the core barrel can be aligned with the sonde rests on the tower. Three movable core barrel holders, that slide the length of the table, are provided for placing the core barrel or hollow shaft on when removing or installing them in the drill. A drip tray runs the full-length of the table to contain the drilling fluid and cuttings and direct them to the chips bucket the sits between the core pullout table and the slot. A head clamp, which attaches over the drill head, is provided to facilitate pulling out the core barrel and hollow shaft. It also covers the cutters to prevent operators from contacting them when handling the barrel. In most cases the core barrel can be pulled out by hand, but if it becomes stuck the hand winch at the end of the table can be used to assist with pulling.

### 11.9 Core Processing System

After the core barrel has been pulled from the drill onto the Core Pullout Table, the barrel is transferred by hand to the core pushout station at the end of the Core Processing System. The ice core is then pushed from the core barrel through the Fluid Evacuation Device (FED) to remove drilling fluid from the core if you are wet drilling. After the FED is a 6 m long section of tray with an ice core saw mounted at the midpoint for measuring and cutting the cores into 1 m lengths. At the end of the tray is a station for putting the core into layflat tubing and then into 1 m ice core tubes. Drawing 8614-0183 *Core Processing Table Assembly* and Figure 20 shows the complete assembly.




Figure 20. Core processing system

The base of the system is comprised of 7 butcher block topped tables. After they are assembled and leveled, the FED, drawing 8614-0184 *FED Assembly*, should be mounted in place. The FED is shown in Figure 21.




Figure 21. FED assembly loaded with netting for brittle ice

Four nearly identical 2 m long rail assemblies mount on the tables next to provide a ridged height adjustable base for the core trays and core barrel. The rail assembly that has black rails and notches cut out of rails at one end should be positioned to the right of the FED with the notches towards the FED as shown in the right-hand picture of Figure 20. The other rail assembly with the black rails mounts to the left of the FED followed by the remaining two rail assemblies. The rail assemblies and tables are marked with a letter to indicate the location of each unit. Aluminum V-trays for holding the ice core, which are also marked with their mounting location, attach onto the rails of the rail assembly using flat head screws with the exception of the tray to the left of the FED. This tray is free to slide so it can be positioned close to the FED for receiving the core and then moved to the left to transfer the core to the other trays. The tray was made to slide so it can be moved out of the way to load the green ice core netting (used when drilling brittle ice) on the FED netting sleeve as shown in Figure 21. Loosely install the rail assembly mounting clamps, but do not fully tighten them until the core trays are aligned. At this time also install the layflat installation fixture at the left end of the core trays. 1 m and 2 m long fiberglass tubes, that have the same 98 mm OD as the ice core, are provided to aid in aligning the core trays with the FED and core barrel. Lastly install the metal cutting chops saw with 14" diameter blade used for cutting the cores to length.

#### 11.10 Vacuum System

Located under the core processing table to the left of the FED is a vacuum system, as shown in Figure 22, that is used to provide suction for the FED and the winch cable cleaner. The system consists of two major components, a regenerative blower and fluid catch canister. On the side of the fluid canister is a fluid level site tube. Be sure to not let the fluid level rise too high or fluid will get sucked into the blower. The outlet to the blower also has a filter to prevent debris from entering the blower. The blower outlet should be plumbed to the branch fitting on the slot ventilation hose that runs right behind the blower in the snow wall. The lid of the canister is removable and all hose fittings on the canister have quick connect fittings so they can be easily removed for servicing or emptying of the canister. When the canister is full, it can be emptied directly into the open tank next to the chip melter. The starter contactor for the blower mounts to the underside of the table and the control panel (containing the E-stop and start/stop buttons) should be mounted to the tent footer above the FED as shown in Figure 21. The starter contactor requires both 120V and 208V power. The 120V cord should be plugged into a multi-tap outlet cord running along the tent footer and the 208V power is fed from a dedicated breaker in the 208V panel. The feeder cord, which ships with the panels, should be buried under the Geoblock with other cables that are coming across the building from the panels. Be sure to remove and lock-out tag-out both power sources before performing any maintenance or service on the blower.




Figure 22. Vacuum system

The smaller black hose can be used for vacuuming fluid off the ice core, general clean up, or connected to the cable cleaner. When using this hose, close the blast gate on the suction hose going to the FED for best suction. The cable cleaner, shown in Figure 23, is very effective at removing drilling fluid from the winch cable when tripping out of the hole. It should be used whenever wet drilling to minimize fluid loss. The black hose connects directly into the side of the attachment which fits around the winch cable. When the cable cleaner is not in use it is stored on brackets under the core processing table.



Figure 23. Cable cleaner

### 11.11 Fluid Handling

Drilling fluid is delivered to the site in 55-gallon drums. Pallets of drums should be staged close to the building as called out in Figure 1 and shown in Figure 24. A drum pump is used to transfer fluid from the drums directly to the borehole.




Figure 24. Pallet of drilling fluid outside the drill tent

The control switch for the pump and hose valve is preassembled on a board that should be mounted to the left of the electrical panels as shown in Figure 13 and Figure 25. The 120V power cord should be plugged into a dedicated outlet on the 208V panel. The blue hose with the quick connect goes between the pump and the control board. Connect a second hose below the valve and run it to one of the fittings on the side of the hole cover. To transfer fluid to the borehole, first insert the drum pump into a full drum. Then open the valve on the control board and turn the pump on. With the hole cover open, you should be able to see fluid coming in. When you hear the pump pitch change, the drum is empty, and the pump should be turned off and the valve closed. A gallon or two of fluid will remain in the drum. Each drum will have to be tipped and emptied into a bucket to recover the remaining fluid.




Figure 25. Fluid handling control board

### 11.12 Chip Processing

The slurry of ice cuttings and drilling fluid, which is recovered from the chips chamber on the drill, is processed in a chip melter to recover about 85% of the drilling fluid. With the tower horizontal, and before the core barrel and hollow shaft are pulled out, a tray is placed between the end of the tower and the slurry pan to prevent the slurry from going into the slot as shown in Figure 26.






Figure 26. Tray for directing the cutting slurry into the slurry pan

Once the slurry has been collected in the slurry pan, it is slid over to the chip melter where it is loaded using a hand scoop. Figure 27 shows the centrifuge being loaded with the hand scoop from the slurry pan. Note that the centrifuge has been replaced with a chip melter, but this action is the same. Instructions on the operation of the chip melter will be included in a future release of this document. If questions arise in the meantime, speak with an IDP engineer.




Figure 27. Transferring the slurry of cuttings and drilling fluid to the centrifuge/chip melter

### 11.13 Ventilation

In order to reduce the smell and vapor associated with using the Estisol 140 drilling fluid (or other drilling fluid), the drill tent has been fitted with three ventilation systems. The first system is the four 12" diameter roof mounted ventilators shown in Figure 9. They are easiest to install at the time the tent is being set up. The second system is the Centrifuge/Chip Melter ventilation. This fan ships in the crate with the centrifuge and should be located to the left of the centrifuge behind the fluid tank as shown in Figure 28. The external portion of the duct work with directional wind cap is visible in Figure 24 next to the drum pump. Note that the centrifuge has been replaced by a chip melter, but this ventilation system is still set up in the same way.



Figure 28. Centrifuge/Chip Melter ventilation

The third system is the slot ventilation. The ventilator is placed outside the drill tent and a flexible 12" hose runs under the floor in the building and down the slot wall in a recessed notch. The slot ventilation system is shown in Figure 29.




Figure 29. Slot ventilation system

The makeup air for all three ventilation systems comes from the mesh vent panel on both end walls of the tent. Both vents should be kept open whenever the ventilation systems are running.

Vent location	Air flow
Roof	4 x 900 cfm
Slot	1054 cfm
Centrifuge/Chip Melter area	400 cfm
Total air flow is 5054 cfm, which provides 22 air exchanges per hour.	

## 12.0 DRILL SONDE

### 12.1 Sonde overview

The Foro 1650 sonde, Figure 30, is the next generation of the Danish Hans-Tausen Drill. It is configurable to drill 2 m long, 98 mm diameter cores in either dry or fluid filled boreholes. Drawing 8614-0527 *Sonde Assembly* shows the complete drill assembly. The winch cable terminates in a three skate anti-torque at the top of the drill. Next in line is the motor section, which includes the motor and gearbox to provide cutter rotation, as well as an electronics package that provides communication with the surface and feedback on parameters such as voltage, current, pressure, temperature, and inclination all within a pressure tight tube. Following the motor section is the chips chamber with internal hollow shaft. The hollow shaft transmits the cutter rotation to the core barrel while the annular space between the hollow shaft and chips chamber tube collects the cuttings generated while drilling a core. The core barrel and outer tube are next in line. The outer tube connects to the chips chamber while the hollow shaft connects to the core barrel. Flights on the core barrel work in conjunction with grooves on the inside of the outer tube to transport the cuttings from the head to the chips chamber. Last in line is the cutter head with replaceable cutters, core dogs, and penetration shoes.




Figure 30. Foro 1650 sonde assembly.

## 12.2 Anti-Torque

The Foro 1650 drill utilizes a three blade anti-torque to centralize the top of the drill and prevent the upper portion of the drill from rotating. See drawing 8614-0030 *Anti-Torque Section* for the full assembly. The anti-torque assembly attaches to the drill cable with a modified EVERGRIP cable termination. This termination allows the winch cable, which has been pre-terminated with a connector, to be easily installed and removed from the anti-torque. The termination is housed within a bearing assembly that allows the anti-torque and winch cable to spin freely of each other. The components of the bearing assembly and cable termination are called out on drawing 8614-0040 *Cable Bearing Assembly*. Figure 31 shows a section view of the anti-torque section. The curve of the three blades is adjusted with the nut assembly, shown in yellow in Figure 31. To set the curve, measure from the OD of the torque tube to the highest point on a blade and set the distance to 58 mm if cutting a 126 mm borehole and 60 mm if cutting a 129.6 mm borehole. This should be a good starting point and may need to be adjusted depending on the firm conditions.




Figure 31: Anti-Torque section view

### 12.3 Motor Section

The motor section, Figure 32, consists of a pressure tube with sealed top and bottom plug assemblies that isolate the internal components from the borehole fluid. Internal components include a brushless DC servo motor, harmonic drive reducer, and electronics. Drawing 8614-0078 *Motor Section Assembly* details the motor section components. The motor section mechanically connects to the anti-torque section with shoulder screws. An electrical cable with pressure-rated connectors connects the anti-torque slip ring to the bulkhead connector in the top plug assembly. 8614-0112 *Foro Drill Bulkhead Seal Installation and Maintenance* describes the procedure for maintaining and replacing the upper and lower bulkhead seals.




Figure 32: Motor Section

### 12.4 Chips Chamber

The chips chamber is a stainless-steel tube between the motor section and the outer barrel of the sonde. The chips chamber connects to the bottom plug assembly with a series of retaining pins that also stabilize the sonde in the borehole. Chips from the cutter head/core barrel assembly are transported into the chips chamber during the coring process and stored there until emptied on the surface. Two versions of the chips chamber are available: a solid tube and a tube with hundreds of small holes. The solid tube is used with a hollow shaft with screened holes that allows drilling fluid into the shaft bore, while the chips chamber tube with holes is used with a solid hollow shaft. Improved performance has generally been achieved with the solid chips chamber and screened hollow shaft with holes. See drawing 8614-0247 *Chips Chamber Assembly* for details.

## 12.5 Hollow Shaft

Torque from the motor section is transferred to the core barrel/cutter head assembly via the hollow shaft, Figure 33. The hollow shaft top coupling connects to the motor section drive plate via three quick-lock pins. Valve assemblies at the top and bottom of the hollow shaft open to allow fluid to flow through the chips chamber and speed sonde descent. The valves should be rotated to the open position manually while the drill is being prepared on the surface. The valves will automatically close when forward cutter rotation is started to keep chips from washing out of the chips chamber during drilling and sonde ascent. A series of helical boosters can be added to the hollow shaft to aid in chip transport up the chips chamber. They attach to the hollow shaft with clamp nuts on the top and bottom. A booster is always used at the bottom of the hollow shaft running inside a housing with axial strips on the inside to increase chip transport efficiency. Additional boosters can be placed on the hollow shaft at any location, but generally only one additional booster is needed directly above the chips valve assembly. A small positive-displacement pump that operates in place of the booster at the bottom of the hollow shaft is also available, but IDP has not had good results using it in the past. Drawing 8614-0210 & 8614-0551 *Hollow Shaft Assembly* details the hollow shaft assembly components.




Figure 33: Hollow Shaft Assembly

## 12.6 Core Barrel

The core barrel assembly transfers torque from the hollow shaft to the cutter head, accepts the ice core as it is drilled, and transports chips from the cutter head to the chips chamber via helical flights, Figure 34. Attachment to the hollow shaft drive plate is accomplished with three quick-lock pins. Two types of core barrel assemblies are available: dry and wet. The dry core barrel has HDPE helical flights that extend out to nearly touch the outer barrel interior, see drawing 8614-0568 *Dry Core Barrel\_Shortened*. The wet core barrel has narrow aluminum flights that only protrude a few millimeters beyond the core barrel tube, see drawing 8614-0621 *Wet Core Barrel Assembly\_Shortened* and function mainly by stirring the chip/drilling fluid slurry, keeping the chips in suspension as they travel to the chips chamber. The positive-displacement pump must be used with the wet core barrel to provide chip transport. Both barrels were originally built with a quick connect “Super Banger” attachment to the hollow shaft drive plate. This feature has since been removed so the barrels attach with the quick-lock pins, as described above. IDP has had the best chip transport efficiency using only the dry core barrel for both dry and wet coring.




Figure 34: Core barrel and outer tube assembly.

### 12.7 Outer Tube

The fiberglass outer tube attaches to the bottom of the chips chamber tube with a slip-joint retained with three custom locking pieces that also act as stabilizers in the borehole. The core barrel rotates within the outer barrel, and the chips transport upward via the helical flights in the annulus between the barrels. Axial grooves on the interior wall of the outer tube provide a reaction surface for the chips on the helical flights which helps to impart vertical motion to the chips. Drawing 8614-0130 *Outer Tube* details the part.

### 12.8 Cutter Head

The cutter head attaches to the bottom of the core barrel with three custom screws/nuts and serves as a mount for the cutters and core dogs, Figure 35. Two types of cutter heads exist: dry and wet. The wet cutter head has a smaller outer diameter to allow the chip slurry to circulate around the head. IDP has had the best success using the dry cutter head for both dry and wet coring. See drawing 8614-0341 *Cutter Head Assembly\_Dry drilling* for cutter head, cutter, shoe, and core dog assembly details.

Several types of cutters are used with the Foro 1650 drill. Dry coring is generally done with regular cutters that cut a 126 mm diameter borehole. Wet coring can be done with regular cutters that cut a 126 mm or 129.6mm diameter bore. IDP has generally had better success using 126 mm diameter cutters for both wet and dry drilling, although the narrower borehole can decrease ascent/descent speeds in deep holes. Step cutters that have geometry that allows each cutter to cut one-third of the annulus are also available. Step cutters create larger chips at low cutting pitch (axial distance per revolution), which can improve chip transport in challenging coring conditions. Step cutters do, however, have a larger depth-of-cut at a given pitch compared to regular cutters which can cause poor core quality in stressed/brittle ice. Step cutters are available in 126 and 129.6 mm borehole diameters. Scoop cutters, where the inner cutting edge is radiused to decrease point stresses on the ice core, are available for use in challenging ice conditions. Varying success has been achieved with scoop cutters in the past, and they are hard to sharpen to a keen edge, so use of them is cautioned.

Cutter shoes are necessary to control the depth-of-cut of each cutter, which also sets the pitch. Specific shoes are used with regular, step, and scoop cutters, respectively. Shoes are available for common pitch depths, and shims can be used to refine the cutter pitch, as necessary. Consult the Foro 1650 Drill Shoe Height spreadsheet to set the appropriate pitch as coring conditions dictate.

The cutter heads have mounts for three core dogs which are used to break and hold the core in the core barrel at the completion of each coring run. Each core dog rotates around a pin that retains it in the cutter head. The normal configuration is for each core dog to be energized by a leaf spring keeping the core dog edge in contact with the core and a light torsion spring pushing the core dog back into the leaf spring. This arrangement can improve core quality in fully dense ice, however, in soft firm this set-up usually reduces the core diameter and makes core recovery difficult. Use of only a light-to-medium strength torsion spring (no leaf spring) pushing the core dog against the ice core is recommended in firm. Long, short, and tear-drop core dogs are available. Long core dogs are used in soft formations, short core dogs are used as the ice densifies, and tear-drop core dogs can be used in place of short core dogs (may actuate better, untested).




Figure 35: Cutter head assembly configured with regular cutters and long core dogs.



Using the correct cutters, pitch, and core dogs for the ice formation being cored is critical for good core quality. Most sites suitable for the Foro 1650 Drill will drill well with regular cutters and a pitch between 5 mm (soft firn) and 0.5 mm (brittle/stressed ice). Penetration shoes are available for these pitches, and shims can be used to fine-tune the pitch further. Step cutters are a good option if chip transport has deteriorated, but the core quality is still acceptable. Scoop cutters can be tried if core quality is unacceptable. Make sure to use the applicable shoe for each type of cutter. Cutter sharpness is extremely important. Cutters should be changed frequently and resharpened/honed if core quality is deteriorating. A used cutter that still appears sharp can negatively affect core quality. Ice that is colder and/or dustier (Greenland, etc.) will dull cutters faster.

Correct core dog length, sharpness, and spring strength can affect core recovery as well as core quality. In general, use longer core dogs in firn and transition to shorter core dogs as the ice densifies. Poor core recovery and/or extensive ice spalls on the core are signs that the core dogs are too long, dull, and/or the spring is too light. Use only a light torsion spring on core dogs in soft firn. Changing to a leaf/torsion spring set-up can improve core quality in fully dense ice that is brittle/stressed. A tapered collet, if available, can improve core recovery and quality in firn and extremely brittle/stressed ice.

## 12.9 Bailer

A chips bailer tool can be attached to the motor section in place of the chips chamber and used to remove unrecovered chips from the borehole, Figure 36. The bailer tool consists of a perforated tube with a filter sock inside, a butterfly valve, and a brushed plunger assembly. Bailer plungers are available for 126 and 129.6 mm borehole diameters, both using the same perforated bailer tube and butterfly valve. Bailer tubes are 2-meters long but can be combined with a coupler to make a 4-meter-long tube. See drawing 8614-0369 *Chips Baler Assembly* for details. Filter socks are available in 400- and 800-micron mesh. In general, use the coarsest mesh that adequately cleans the borehole. Fine meshes and felt liners significantly slow the downward travel of the bailer tool through the borehole fluid column. Filter bags are attached by removing the butterfly valve housing and retaining the metal ring of the filter bag between the housing and the perforated tube end. When descending the bailer downhole, watch the cable tension closely to ensure that the bailer sonde does not float in the fluid column. At the end of the bailer downhole run the butterfly valve will close and the plunger assembly will actuate to let fluid bypass around the outside of the bailer sonde. On the surface remove the butterfly valve housing and pull out the full filter sock. If the filter sock sticks inside the perforated tube, use light vibration (light taps with a rubber mallet) to loosen the chips enough to pull the filter sock out without ripping it. Dispose of the chips in the hopper to be run through the centrifuge/chips melter. Clogged filter socks can be melted out in a hotbox, chips melter tank, or allowed to sublimate in the sun.




Figure 36: Chips bailer.

### 12.10 Reamers

Reamers are used to increase the diameter of the borehole to allow for the installation of casing tubes in firm, Figure 37. Two-stage reaming is necessary with the Foro 1650 drill to make the borehole large enough for the 8-5/8" diameter HDPE casing currently used; 7-inch and 9-inch. The reamer assembly attaches to the bottom of the motor section in place of the hollow shaft, chips chamber and core barrel/outer tube assemblies. See drawings 8614-0141 *Reamer\_7 inch Assembly* and 8614-0146 *Reamer\_9 inch Assembly* for details on the reamer assemblies.




Figure 37: 7 inch and 9 inch reamers.

## 13.0 DRILL RUN OPERATIONS GUIDE

The Drill Run Operations Guide in section 17.0, Appendix C, provides step by step instructions for completing a drill run. This guide is especially useful for new or returning operators to ensure all steps of a drill, along with safe winching speeds, are followed. Print this guide and keep out for reference in the control room.

## 14.0 WINTERIZING FOR MULTI-YEAR PROJECTS

With some preparation, most of the drill system can safely remain on site and winter for multiple season projects. Any equipment that will not be able to handle the extreme winter-over temperatures should be removed and shipped out for warm storage. Items that must be removed include the following.

- Winch/tower control box.
- Console and laptop.
- Level wind assembly.
- Drill motor sections.
- Control room ERV control boards.
- Centrifuge controller case (if using the centrifuge instead of the chip melter).
- Cordless tools and batteries.

Any equipment requiring maintenance or repair should be shipped back to IDP. This often includes cutters and core dogs and the motor sections. Spare parts kits for the components being returned should also be sent with them.

It is recommended to add internal anchors between the tent frame and ice to ensure the integrity of the tent during the winter months while no one is around to check on it. Eight screw-in ground anchors are supplied with the system for this. Evenly space and install four anchors along each side wall and in line with one of the tent frame arches. Attach the hook end of a cargo strap to the tent frame with a loop of rope or webbing, as shown in Figure 38 A. Attach the ratchet end of the cargo strap to the ground anchor, as shown in Figure 38 C. Evenly tension the eight cargo straps once they are all in place, Figure 38 B.




Figure 38: **A** – Strap connection on the tent frame. **B** – Drill tent secured from the inside for the winter. **C** – Strap attached to a ground anchor.

Cover the slot ventilation fan with an empty shipping crate and secure it with a strap and snow pickets, Figure 39. Brace or secure the two entry doors on the inside to ensure they won't blow open during high winds, Figure 40. After bracing the doors, exit through the zippered cargo door and secure it closed and bury the snow flap. The four wind directional roof vents do not need to be removed or sealed for the winter. On past projects, little to no snow has entered through the vents during the winter. Make sure all shipping cases and crates are well flagged and secured by strapping them together and to the pallets.




Figure 39: Cover over the slot ventilation fan.



Figure 40: Bracing at the bottom and mid-point of the entry door.

## 15.0 SHIPPING AND INVENTORY LISTS

Copies of the current packing and inventory lists are available on the IDP SharePoint site at IDP – Documents\Shipping\Proformas\Foro 1650.

16.0 APPENDIX A: PREVENTIVE MAINTENANCE CHECKLISTS

<b>Foro 1650 Preventive Maintenance Checklist</b>			
<b>WEEKLY CHECKS</b>		<b>WEEK OF: _____</b>	
ITEM	ACTION	DATE	INITIALS
<b>CHIP MELTER</b>			
Drain valves	Inspect for damage/leaks/ice buildup		
Chip melter body	Inspect for damage		
<b>CONTROL SYSTEM</b>			
Data	Perform data archiving		
<b>FLUID HANDLING SYSTEM</b>			
Drum pump	Inspect for wear/damage/leaks		
Hose and valves	Inspect for leaks		
<b>TOOLS</b>			
Tools	Inspect for damaged/missing tools		
<b>POWER DISTRIBUTION</b>			
Power cabinets/equipment	Inspect for damage		
Cables	Inspect for cable/insulation damage		
<b>SLOT</b>			
Floor-wall liner	Inspect for functionality and damage. Clear slush/verify casing drainage holes are open		
Hose-casing connection	Verify proper connection of fluid hose to casing		
<b>SONDE</b>			
Components	Verify free of damage, leaking oil/grease.		
<b>TOWER/WINCH/LEVEL WIND</b>			
Crown sheave	Inspect for damage and ice buildup		
Components	Inspect for damage/fluid and ice buildup		
Cabling	Inspect for wear/damage at connections		
<b>VACUUM FOR FED AND CABLE CLEANER</b>			
Check tanks	Empty as needed		
<b>CONTROL ROOM</b>			
Structure and fabric	Inspect for damage		
Heater	Verify function		
<b>DRILL TENT</b>			
Structure and fabric	Inspect for damage		
Directional wind caps	Verify they are free of snow and operating properly		
<b>COMMENTS:</b>			

## Foro 1650 Preventive Maintenance Checklist

### SEASONAL CHECKS (to be performed once per drill season)

ITEM	ACTION	DATE	INITIALS
<b>CABLE</b>			
Cable/cable termination	Inspect for damage		
<b>CHIP MELTER</b>			
Tank	Inspect for damage, verify that there are no leaks		
Valves	Inspect for clogs, verify open/close function		
Heater	Verify function, set thermostat to ~60F (15C)		
Heater guard/screen	Inspect for damage and clean as needed		
Power cabling	Inspect cables and connectors for damage		
<b>CONTROL SYSTEM</b>			
Hard stop switch on tower	Verify function		
Sonde home switch	Verify function		
Cable payout/tension sensor	Check calibration		
E-Stops (5)	Verify function		
Control box wiring	Check for loose connections		
Control box heater	Verify function		
Control box cooling fan	Verify function of fan and thermostat		
<b>CONTROL ROOM</b>			
Structure and fabric	Inspect for damage		
Heater	Verify function		
<b>DRILL TENT</b>			
Structure and fabric	Inspect for damage		
Directional wind caps	Verify they are free of snow and operating properly		
<b>CORE PULL OUT TABLE</b>			
Table	Verify alignment with drill on the tower		
Table fasteners	Check for loose connections		

## Foro 1650 Preventive Maintenance Checklist (Continued)

### SEASONAL CHECKS (to be performed once per drill season)

ITEM	ACTION	DATE	INITIALS
<b>CORE PROCESSING</b>			
Core processing system	Verify alignment of core barrel, FED and core trays		
FED	Verify operation and unit is free of chips		
Core saw	Verify operation and inspect for damage		
<b>FLUID HANDLING SYSTEM</b>			
Fluid hoses/plumbing	Check for damage and leaks		
Drum pump	Inspect for functionality and damage		
<b>SAFETY EQUIPMENT</b>			
Batteries	Check for dead/leaking batteries		
Lifting straps	Inspect for damage/wear		
<b>SONDE</b>			
Connections	Verify secure connections		
Grounding	Verify ground continuity		
<b>TOWER</b>			
Grounding	Verify ground continuity		
Tower assembly	Inspect for damage		
Tower fasteners	Check for loose bolts/torque as needed		
Tower/Sonde alignment	Adjust sonde rests as needed		
Actuator	Inspect for functionality/brake operation		
Crown sheave	Verify smooth rotation; check before cable is connected		
<b>WINCH/LEVEL WIND</b>			
Winch system	Inspect for damage		
Winch gear box	Check torque on shrink disk (shaft connection)		
Winch drum	Check torque on drum flange bolts		
Winch motor	Inspect for functionality/brake operation		
Level wind	Inspect for functionality/brake operation		
Level wind drive belt	Inspect for damage and proper tensioning		
Level wind slide	Grease w/ Shell Aero 7 as per manual		
<b>COMMENTS:</b>			

**17.0 APPENDIX C: FORO 1650 DRILL RUN OPERATIONS – REFERENCE GUIDE**

Please complete all fields on the drill run sheet and take detailed notes to document drill performance or changes made to the drill configuration.

**Note:** The computer has speed limits set for when the drill is near the surface or bottom. If the speed limits are exceeded the screen background will turn yellow and the speed display will flash red. This is only a warning indicator; it is up to the operator to slow down.

**Note:** All distances denoted in (m) or (mm) refer to cable payout distances.

- 1) Ensure 'WOB limit' is set to 600 N on the computer
- 2) Start new drill run in the logbook and press **New Run** in LabView
- 3) Make sure the floor operator has opened the hole cover
- 4) Set the winch to pay-out and lower sonde until sonde-at-home light goes out
- 5) Set winch to pay-in and slowly raise sonde until sonde-at-home light turns green; the winch will automatically stop when the switch is engaged
- 6) Press the reset button twice on the LCI-90i to **ZERO PAYOUT DEPTH**
- 7) Zero WOB by pressing the **WOB RESET** on the computer screen
- 8) Set the winch to pay-out and lower the drill no faster than **0.15 m/s** while the drill is on the tower and entering the casing
- 9) Ensure the floor operator checks that the cable bearing rotates freely
- 10) Close the hole cover
- 11) Trip down at **0.50 m/s** to 130 m, or until the drill is below the casing
- 12) When you see the WOB increase as the drill enters the drilling fluid, click **RECORD FLUID LEVEL** on the computer; record the fluid level in the logbook
- 13) Increase speed to **1.0 m/s**, keeping your EDW (Effective Drill Weight) above 100 N; the background on the computer screen will turn red and the EDW display will flash red if the EDW is in alarm; it is up to the operator to slow down! The control system will not do it for you.
- 14) Start gradually slowing descent around 20 m from bottom
- 15) About 1 m above the previous end depth slow down to 0.03 m/s and trip down slowly while watching WOB; either stop 0.02 m from the displayed bottom or stop payout when WOB increases and you touch bottom; if you touch off bottom, be sure to raise the drill until all of the WOB comes off before turning the cutter on



- 
- 16) Set drill toggle switch to forward and set the input voltage to **500 Volts**
  - 17) Turn the A-T slip siren on (toggle switch on console)
  - 18) Set the winch payout speed, using the coring knob, to **3.0 mm/s**; **Adjust as needed according to previous drill run speeds noted in logbook**
  - 19) When the cutter current spikes, you are now cutting ice; press **DIFF RESET** on the console and/or **RESET DELTA** on the computer to reset delta Depth
  - 20) Adjust speed feed rate as needed (i.e. if cutter current is jumpy or if WOB is climbing significantly, slow your speed by a few tenths; if the cutter is dropping out, increase your speed by a few tenths)
  - 21) Stop paying out if the cutter current spikes, WOB spikes, or if other adverse events are witnessed; otherwise, stop at your desired core length
  - 22) Stop the cutter if the A-T siren starts going off at a rapid interval
  - 23) Stop Payout, when the current drops and Tension/WOB stabilize (~20 seconds) turn off the cutter and set the direction switch to stop
  - 24) Turn off A-T Slip siren
  - 25) Record end depth and delta depth in the logbook
  - 26) Set winch direction to pay-in; quickly turn tripping knob halfway (pointer at 12 o'clock) and break core
  - 27) Record Max Tension in the logbook
  - 28) Continue your ascent after the core break and slowly increase ascent speed up to **1.4 m/s** (max speed of the winch) or as conditions permit
  - 29) Approximately 10 m before you exit the recorded fluid level, slow to **0.5 m/s**
  - 30) Further decrease speed to **0.3 m/s** while the drill is in the casing
  - 31) Open the hole cover
  - 32) When the drill begins to come out of the casing, decrease speed to **0.15 m/s**
  - 33) When the sonde engages the sonde-at-home switch the light on the console will turn green and the winch will automatically stop
  - 34) Set the winch speed knob to zero and the direction switch to stop
  - 35) Complete the drill run entry in the logbook
  - 36) Begin surface operations

**18.0 APPENDIX B: DRILL LOG TEMPLATE**

**Note:** Logs can be maintained as hardcopy or electronic

Run Number:	Date:	Run Start Time:	Drillers:	
Previous End Depth (M):	Start Depth (m):	End Depth (m):	Delta Depth (m):	
Drill Voltage:	Fluid Level (m):	Max Break Tension (N):	Actual Core Length (m):	
Drilling Speed:	<b>DRILL CONFIGURATION</b>			
	Anti-Torque: A      B	Motor Section: 1      2	Chips Chamber:	Core Barrel:
	Cutter Head:	Cutter Set:	Shoe Pitch:	Anti-Torque setting:

**Notes:**

Run Number:	Date:	Run Start Time:	Drillers:	
Previous End Depth (M):	Start Depth (m):	End Depth (m):	Delta Depth (m):	
Drill Voltage:	Fluid Level (m):	Max Break Tension (N):	Actual Core Length (m):	
Drilling Speed:	<b>DRILL CONFIGURATION</b>			
	Anti-Torque: A      B	Motor Section: 1      2	Chips Chamber:	Core Barrel:
	Cutter Head:	Cutter Set:	Shoe Pitch:	Anti-Torque setting:

**Notes:**